

File Edit View Insert Format Tools Data Window Help Adobe PDF

Type a question for help

Arial 10 B I U

Reply with Changes... End Review...

	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O	P	Q	R
1	<b>Switching Frequency Results</b>																	
2																		
3	dt(on) = L*dl/V(on)			where dl includes tpdly and tsw_off factors														
4	dt(off) = L*dl/V(off)			where dl includes tpdly and tsw_on factors														
5	Fsw = 1/(dt(on) + dt(off))																	
6																		
7																		
8	<b>Fast-Charge</b>																	
9																		
10	<b>Vbatt min</b>																	
11	Vl(on)	2.045		los_neg	1.74E-02		lcharge pk-pk	2.814E-01		dt(on)	6.468E-06							
12	Vl(off)	2.822		los_pos	2.40E-02						dt(off)	4.687E-06						
13	Fsw-fc(Hz)	8.96E+04																
14																		
15	<b>Vbatt nom</b>																	
16	Vl(on)	1.145		los_neg	9.74E-03		lcharge pk-pk	2.814E-01		dt(on)	1.155E-05							
17	Vl(off)	3.722		los_pos	3.17E-02						dt(off)	3.554E-06						
18	Fsw-fc(Hz)	6.62E+04																
19																		
20	<b>Vbatt max</b>																	
21	Vl(on)	0.745		los_neg	6.34E-03		lcharge pk-pk	2.814E-01		dt(on)	1.775E-05							
22	Vl(off)	4.122		los_pos	3.51E-02						dt(off)	3.209E-06						
23	Fsw-fc(Hz)	4.77E+04																
24																		
25																		
26																		
27																		
28																		
29																		
30																		
31																		
32																		
33																		